

Assembly Instruction For 13500

- 1. Thread the nipple then secure by hex nut.
- 2.Attached glass, rebber washer, metar washer in order like the drawing then secure by hex nut.
- 3. Attached cap then secure by finial.

